

## Dräger PARAT® 4500 Industrial Escape Hood



Take the hood into both hands.



Push out the filter ...



... using both thumbs.



Open the elastic neck seal using both hands.



First insert your chin into the hood resting it inside the inner mask.



Pull the hood over your head. Make sure that your nose and chin sit comfortably in the inner mask and that all your hair is tucked into the hood.



Tighten the strap ...



... until the inner mask lies firmly over your mouth and nose.

## Dräger PARAT® 4500 Industrial Escape Hood



### SOFT PACK



Handy travel case.

At first pull the Velcro® band open.



Open the zipper of the Soft Pack and remove the hood.



Hold the red pull cords in one hand and use your other hand to pull the hood until both filter seals are opened.



The filter openings must be free to ensure unrestricted breathing.

### TRAVELLER PACK



Robust plastic casing for rough environments.



Remove the metal clamp to open the box and remove the hood.



Hold the red pull cords in one hand and use your other hand to pull the hood until both filter seals are opened.



The filter openings must be free to ensure unrestricted breathing.